

Stock Service Entrance Switchboards

Super Blue Pennant Switchboards

Accessories

Description	Catalog Number
Underground Pull Section or Full Height Section For Load Wiring — Discount Schedule SWBD	
14.5" Deep 90" High 14" Wide (12" opening) — indoor 15" Wide (12" opening) — outdoor	PUG14 WPUG14
26" Wide (24" opening) — indoor 27" Wide (24" opening) — outdoor	PUG26 WPUG26
10" Wide (load wiring)	PLW10

Lug Landing Kits — Discount Schedule SWBD (Requires Catalog Number PUG26 or WPUG26)

400A	1-Phase, 3-Wire or 3-Phase, 4-Wire	PLL44 ^①
600A	1-Phase, 3-Wire or 3-Phase, 4-Wire	PLL46 ^①
800A	1-Phase, 3-Wire or 3-Phase, 4-Wire	PLL48 ^①

"R" Fuse Clip Adapter Kit (Set of 3) — Discount Schedule VBSS

400A 250/600V	SSRK35
600A 250/600V	SSRK36

"J" Fuse Clip Adapter Kit (Set of 3) — Discount Schedule VBSS

400A 250V	W49814
400A 600V	W49816
600A 240V	W49813
600A 600V	W49815

"T" Fuse Clip Adapter Kit (One Pole Kit) — Discount Schedule VBSS

400A 240V	TFAK52
400A 600V	TFAK55
600A 240V	TFAK62
600A 600V	TFAK65

Optional Meter Sockets and Doors — Discount Schedule SWBD

Meter Compartment Door (32" Wide x 15" High for "S" base socket with test block cutout (order necessary meter base from items below)	PSP32
Meter Compartment Door (32" Wide x 30" High) for 2 "S" base meters with mounting provisions for test block and printing demand meter (order meter base from table below) Left Hand Hinge or Right Hand Hinge	PSDP32
Blank Meter Compartment Door (32" Wide x 15" High)	PBP32
5 Clip Meter Socket with ring	PMS5
6 Clip Meter Socket with ring	PMS6
8 Clip Meter Socket with ring	PMS8
13 Clip Meter Socket with ring	PMS13
15 Clip Meter Socket with ring	PMS15

Filler Plates — Discount Schedule MCCB

QP, BL, BQD, xGB, xGB2, ED	QF3
----------------------------	-----

Handle Blocking and Padlock Devices — Discount Schedule MCCB

Blocking (QP-HQP 1, 2 and 3-pole)	ECQL1
Blocking (QR2, QRH2, HQR2, HQR2H)	HBLQR
Blocking (ED2, ED4, ED6)	E2HBL
Padlock (QP-HQP)	ECQLD3
Padlock (QR2, QRH2, HQR2, HQR2H)	HPLQR
Padlock (ED2, ED4, ED6)	ED2HPL

Equipment Ground Bus — Discount Schedule SWBD

	PEGB42
--	--------

For inches / millimeters conversion, see conversion table in Application Data section.

① A PUG26 or WPUG26 Underground pull section is required when using these lug landing kits.

☐ = Warehouse Stock