

Manual Supplement

Manual Title: 714C Users
Part Number: Web-Only
Print Date: January 2014
Revision/Date:

Supplement Issue: **1**
Issue Date: 12/14
Page Count: 1

This supplement contains information necessary to ensure the accuracy of the above manual.


Change #1, 97

On page 13, following the **Auto Backlight-Off**, add:


External CJC

The Product provides an external CJC option. This option lets you replace the internal CJC with an external cold junction compensation.

To enable External CJC mode:

1. Push .
2. When SHIFT shows on the screen, push TC TYPE.
3. In the displayed setting list, highlight the **External CJC** option. Use  to select option.

To disable External CJC mode:

1. Push .
2. When SHIFT shows on the screen, push TC TYPE.
3. In the displayed setting list, highlight the **External CJC** option. Use  to deselect the option.