

Holdings & Blocks For Branch Circuit Rated Fuses

Class	Fuses	Volts	Page
L	KRP-C_SP	600V	26
	KRP-CL	600V	27
	KLU	600V	28
	KTU	600V	28


Blocks

- 51215 1-pole, panel mount*
- 51235 3-pole, panel mount*

*Call our customer satisfaction team at 636-527-3877 for more information.

Disconnects

- FD800L3 fusible disconnect switches 340



FD400J3



51215



51235

Low Voltage
Branch
Circuit
Fuses

Class	Fuses	Volts	Page
RK1	LPN-RK_SP	250V	29
	LPS-RK_SP	600V	29
	KTN-R	250V	32
	KWS-R	600V	33

Blocks

- R250 Series 1- to 3-pole 250V, panel mount 260
- R600 Series 1- to 3-pole 600V, panel mount 263



R250 Series



R600 Series

Class	Fuses	Volts	Page
RK5	DLN-R	250V	34
	DLS-R	600V	34
	FRN-R	250V	35
	FRS-R	600V	36

Blocks

- R250 Series 1- to 3-pole 250V, panel mount 260
- R600 Series 1- to 3-pole 600V, panel mount 263



R250 Series



R600 Series

Class	Fuses	Volts	Page
T	JJN	300V	38
	JJS	600V	39

Blocks

- BH Series modular-style, panel mount (<60A) 275
- T300 Series 1 to 4-pole 300V, panel mount 269
- T600 Series 1 to 3-pole 600V, panel mount 271

Disconnects

- CDF30J3 fusible disconnect switches 330
- FD400J3 fusible disconnect switches 340



BH Series



T300 Series



T600 Series